

READ ME FIRST

For use with EcoPLUS CF258A/X and CF289A/X/Y

Our EcoPLUS CF258A/X and CF289A/X/Y are a Remanufactured Toner Cartridge with a used OEM chip. The printer will prompt toner low message when installed, please ignore the message and continue with print activities. Replace toner cartridge when signs of fading or low image density occur during print jobs.


For CF258A/X

Step 1.

"**Used or counterfeit cartridges**" message will occur when a replacement toner cartridge with old OEM chip is installed.

pic-01 and pic-02 will flash in sequence every 3 seconds, press **OK** to continue.

Your printer is now ready. Repeat Step 1 whenever new replacement toner cartridge is installed.



For CF289A/X/Y


Step 1.

"**Used Black Cartridge in use**" message will occur when a replacement toner cartridge with old OEM chip is installed. Press "**Exit**" to continue.

Step 2.

"**Used Black Cartridge installed**" message will now occur, press "**OK**" to pass the warning message.

Your printer is now ready. Repeat Step 1 & 2 whenever new replacement toner cartridge is installed.



All package includes a FREE returns label for recycling purpose, please pack and return used OEM toner cartridge or EcoPLUS remanufactured CF258A/X and CF289A/X when used up.