


# HP M507 (CF289A/X/Y)

# CLOVER



IMAGING GROUP

- 1 The below message(s) will be displayed upon install.

“OK” will need to be selected to be able to print.



- 2 Select “Exit” two times to get back to the menu page.




- 3 Warning / Error symbol will remain present at top right of the display.




- 4 You can print a supplies status page by selecting the “Supplies” icon.

No Toner low or Very low messages will be present.


End of life will have to be established by faded print.



1 Select "OK".



2 Select "Exit".



3

- Toner warning light will stay on.
- Can print SSP but will just state used.
- End of life will have to be established by fade.

